PIONEER
The Art of Entertainment

Service Manual

ORDER NO.
RRV1186

SPEAKER SYSTEM

S-W33 XEE

● **This product is a system(s) component. This product's instructions are contained within the instruction manual of the related system component(s). The manual is packed with those component(s).**

● The woofer is attached to the inner baffle by 4 external screws.
To detach it, first remove back-boad.
The back-boad is attached by the 8 screws.
When attaching woofer, face its terminal rightward and leftward.
The woofer has two terminals(L, R).

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan
PIONEER ELECTRONICS SERVICE INC. P.O.Box 1760, Long Beach, California 90801 U.S.A.
PIONEER ELECTRONICS OF CANADA, INC. 300 Allstate Parkway Markham, Ontario L3R 0P2 Canada
PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087 Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS AUSTRALIA PTY.LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL:[03]580-9911
© **PIONEER ELECTRONIC CORPORATION 1994**
T-FFV AUG 1994 Printed in Japan

PARTS LIST

NOTES:

- *Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.*
- *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore,when replacing, be sure to use parts of identical designation.*
- *Parts marked by " ⊙" are not always kept in stock. They delivery time may be longer than usual or they may be unavailable.*

Mark	No.	Description	Part No.
		Network assy	SWN1429
		Badge	FRAM−002
		Acoustic absorbent(for duct)	FRMT−068
		Acoustic absorbent(for cabinet)	FRMV−004
		Acoustic absorbent(for partition)	FRMV−005
		Mesh	FRNC-002
		Speaker(Woofer)	20-181A
		Screw(for back board of cabinet)	RA81−4×35
		Screw(for input terminal)	RA81−3×14
		Screw(for network assy)	RA81−5×12
		Screw(for woofer)	RA81−5×16

For Packing

Mark	No.	Description	Part No.
		Accessories assy	FREA−004
		Protector(for top and bottom)	FRHA−035
		Protector(for right side)	FRHB−001
		Packing case	FRHG−123
		Polyethylene bag S4	FRHL−018
		[Accessories assy]	
		Foot	SXK1029
		Screw(for foot)	TMZ40P160FZB

SCHEMATIC DIAGRAM AND PARTS LIST

NETWORK ASSY(SWN1429)



(Not distinguish between L and R side for terminals.)

Mark	No.	Description	Part No.
		[Network assy]	
		L1,L2 Choke coil(12.0mH)	STH1180